



# Setup Guide



EN	Setup Guide	RU	Руководство по установке
CS	設定指南	TH	คู่มือการตั้งค่า
CT	安裝指南	ID	Panduan Penyetelan
VN	Hướng dẫn cài đặt	AR	دليل الإعداد
FR	Guide d'installation	PR	راهنمای نصب

## BRAVIA

FW-85BZ40L / 85BZ30L / 75BZ40L  
 FW-75BZ35L / 75BZ30L / 65BZ40L  
 FW-65BZ35L / 65BZ30L / 55BZ40L  
 FW-55BZ35L / 55BZ30L

**1**

SB1 SB2 IM  
 FB VS CL

★2 ★1

1.5 N·m/1,5 N·m  
 (15 kgf·cm)

85  
 75  
 65  
 55

**2**

**3**

★2

**4**

5 (A)  
 5 (B)

**5 (A)**

1  
 2  
 3

VS

SONY

\*1 Refer Reference Guide / 参阅参考指南 / 参阅参考指南 / Tham khảo Hướng dẫn Tham khảo / Consultez le Guide de référence / См. "Справочник" / โปรดอ้างอิงจากคู่มืออ้างอิง / Lihat Panduan Referensi / الرجوع إلى الدليل المرجعي / به راهنمای مرجع مراجعه کنید /

\*2 Only for limited region/country/model. / 仅针对有限的地区/国家/型号。 / 仅限特定区域/国家/型号。 / Chỉ dành cho một số khu vực/quốc gia/model. / Uniquement pour certaines régions, certains pays ou certains modèles. / Только для определенных регионов/стран/моделей. / สำหรับบางภูมิภาค/ประเทศ/รุ่นเท่านั้น / Hanya untuk kawasan/negara/model tertentu. / فقط برای بعضی مناطق/کشورها/مدلها. / لمناطق/بلدان/موديلات محددة فقط.



